How to Make an STL File from a Revit File

This tutorial will go through the steps to creating an STL file using Revit and Fusion 360. This method can be used with both Revit 2019 and Revit 2020.

Converting the Revit File to a DXF

Start by making a copy of the floor plan you are choosing to 3D print. In the copy of the floor plan remove all components that are not floors and walls. To ensure having the best quality print it is necessary the body being printed only includes floor and walls.

Once your model is only composed of floors and walls go to File -> export -> CAD Formats -> DFX (as show in Figure 1). Once you have selected DFX you will be prompted to the window show in figure 2.

RECE.	<u>⇔∘⇔⊨•.⊁⊘∧∣⊜•⊅</u>	#101 (B++	Autodek Revt 2000.1 - STUDENT VERSION - Test File - Rior Plans Level 1	• 🌐 🚨 Sign In 🛛 • 😿 🤇)· _ □ ×
File Architecture	Structure Steel Systems Insert Annotab	e Analyze Mass	tå Site Cellebarite View Manage Add-Ins MedRy ⊡•		
96	Creates exchange files and sets options.	i 🕞 🗑	目 閏 事 ◇ ◇ △ \		
New >	CAD Formats	🔄 DWG	unter Multon Kaing Karng Star Model Model Model Model Model Store Karn Karn Isa Isa Isa Isa Isa Isa Isa Isa Isa Grid Race		
_	(CAD) Creater DWG, DW, DGH, & SA Hart.	DXF	Circulation Model Room & Area * Opening Datum Work Plane		
Dpen +	DWF/DWFx	DGN			
	Creates Diver or Divertifies.	acis (SAT)			
Sove .	FBX Saves a 3D view as an FBX file.	_			ą.
Save As 🔸	Family Types				10.
-	Exports family types from the current family to a test (1st) file.		× ·		
Export +	gbXML Saves the model as a gbXML file.				
Print >	🙊 FC				
Close	ODEC Database				
	Options Exit Revit				

Figure 1: Finding the Export Feature on Revit

In the DFX Export window verify the correct floor plan is being exported and select next.



Figure 2: DFX Export Window

You will be directed to save the file as shown in figure 3. Once ok is selected the floor plan will be exported into a DFX format.

Save in:	Downloads				~	¢ 6	3 ×	Щ.	Vie
History History Documents Favorites Desktop Up Computer	Name	^	Date modified This folder is empty	Туре			Size		
y Network	File name/prefix: Files of type:	Test File - Floor Plan - Lo AutoCAD 2018 DXF Files	evel 1 : (*.dxf)				-		

Figure 3: Saving the DFX File

Exporting a DXF File into Fusion

First open a blank Fusion File. Then proceed to Open -> Open from my Computer -> Select the correct file -> Open. Back on the Fusion Design Space, the floor layout should load. Please note that it is only two dimensional. All these steps are illustrated in figures 4-6.



Figure 4: Starting a New Fusion File

000		Autodesk Fusion 360 (Education License)	
		Turtitled	× + 🤈 🕲 Rosa Hernandez 🕜
	SURFACE SHEET METAL TOOLS CREATE TOOLS CREATE TOOLS MODIFY TOOLS		
+ BROWSER	•		
Origin	Open	×	Z Read Read
		My First Project	
	Demo Project	NAME OWNER LAST UPDATED	
	My First Project	Summer Grave Rosa Hernandez 08/27/2019, 15:44:56	
	Samples	1	
	Workshops & Events		
	CAM Samples		
	Design Samples	1	
	Generative Design Samples		
	Basic Training		
	Open from my computer	Cancel Open	
COMMENTS	0)	⊕▼≜ ở ඥ ♀▼ ∰▼ ∰▼ ∰▼	
			\$

Figure 5: Choosing Where to Open the File From



Figure 6: Floor Layout in Fusion



Scaling the Model

In order to ensure that the walls and floors are extruded correctly, the model needs to be first scaled down. The model will be scaled so the length and width of the building does not exceed 7 inches (177.8 mm). To scale the model the sketch for the floorplan has to be edited. In the browser tab, under sketches, find the sketch for the walls, right click and select edit sketch.

In order to use the scale feature on Fusion you will need to select a point that is not part of the components being scaled. As shown in figure 8 click on the dropdown menu on the Create tab and select point, this will allow you to create a sketch point.



Figure 8: Finding the Point Feature

Once you have selected the point feature on Fusion click anywhere on the sketch to set

the point. Please ensure the point you place is outside of the floorplan as shown in figure 9.

• • •		/	Autodesk Fusion 360 (Educat	on License)	
III ■ ▼ □ ← ▼ → ▼	¢	🕽 Untitled	×	🗊 Test File – Floor Plan – Level 1*	× + 🧿 🕲 Rosa Hernandez 🕜
DESIGN V					
	CREATE V	MODIFY V	CON	TRAINTS 🔻	INSPECT V INSERT V SELECT V FINISH SKETCH V
	•)	Draw point		10000	FRONT X

Figure 9: Creating a Point

Once the point has been placed the next step would be to use the sketch scale feature. Click on the dropdown menu in the modify tab and select sketch scale (shown in figure 10).

C					Autodesk Fusion	360 (Education License)			
8	• • •	$ \bullet \bullet$		🗇 Untitled	×	🗊 Te	est File – Floor Plan – Level 1*	× + 0 @	Rosa Hernandez 🕜
	DESIGN 🔻		SURFACE FORM	MESH TOOLS			√ ◎ ≯ (¦) ≯	INSPECT V INSERT V SELECT V	FINISH SKETCH 🔻
*	BROWSER	Insaved) (*) cument Settings med Views Origin	•	Fillet ♥ Trim T → Extend → Break Sketch Scale :			15000		FRONT
		Sketches		Move/Copy M	Scales sketch geometr Select sketch geometr the scale factor.	y. y to scale then specify	10000	Options Construction Look At	ETTE >>

Figure 11: Finding the Sketch Scale Tool

To use the sketch scale tool, first select the entities that are to be selected. Make sure that everything that is part of the floor plan is selected, that includes everything in the sketch but the point that was created. In the sketch scale pop up box (shown in figure 12) select point and select the point that was drawn.

• • •					Autodesk F	usion 360	(Education	n License)					
	$ \bullet \ \$		🗇 U	ntitled		×			Test File – Floor Plan – Level 1*		× -	- 0 C	Rosa Hernandez 🛛 🕜
DESIGN 🔻		SURFACE FOR CREATE V				= /	CONST		2 ◎ Y 印 *	INSPECT ▼	INSERT T		FINISH SKETCH V
BROWSER	nsaved) ument Settings ned Views Origin	• 1							15000				FRONT
4 © jill,	Sketches,					· · · · · · · · · · · · · · · · · · ·			10000		SKETCH PALETTE	SKETCH SCAL ntities 75 Dint 8 Se	E >>>
							ľ		0	Ĭ			

Figure 12: Sketch Scale Pop-Up

Once the entities and point have been selected, the scale factor can be designated in either of the pop-up boxes shown in figure 13. The floorplan should be scaled down so neither the width or length exceeds 7 inches (1778.8 mm), this is to ensure that the floor plan fits on the Ultimaker build plate. It may take multiple attempts of scaling to achieve the desired dimensions.



Figure 13: Designating the Scale Factor

To check if the length and width do not exceed 7 inches, the measure feature on Fusion can be used. Click on the dropdown menu under the Inspect tab and select Measure as shown in figure 14. To use the measure tool simply select two points, the distance between those two points will be displayed.

		Autodesk Fusion 360 (Ed	ducation License)		
■ ■ ▼ ■ ≤ ▼ → ▼	🗊 Untitled	×	🗊 Test File – Floor Plan – Level 1*	× 🕂 🧐 🕲 Rosa Hernar	ndez 🕜
	SURFACE FORM MESH TOOLS SK CREATE V MODIFY V	етсн , (), = //	$_{\operatorname{constraints}_{\bullet}} \bigtriangleup \bigodot _{\bigcirc} \checkmark [:] ~ \curlyvee$	INSPECT V INSERT V SELECT V FINISH S ETC	CH v
BROWSER BROWSER Decument Settings Decument Settin	•)		Reports distance, angle, area, or position data of the selected object. Select a vertex, edge, face, body, or component.	Measure Validae Validae Validae Comb Analysis Jebra Analysis Oraft Analysis Oraft Analysis Corruture Map Analysis Accessibility Analysis Section Analysis Section Analysis Center of Mass Component Color Cycling Toggle ON	RONT X SKETCH PALETTE

Figure 15: Finding the Measure Tool on Fusion



Figure 14: Using the Measure Tool

Extruding the Walls

Click on the drop-down menu under the Create Tab and select Extrude (as shown in figure

16).





Using the setting shown in the Extrude pop-up in figure 16, select the floor plan and



extrude it 12.5 mm.

Figure 17: Using the Extrude Tool



Figure 18 shows the how the model should look like once the floors have been extruded.

Figure 18: Extruded Floors

Creating the Floor

In order to create a floor a new sketch needs to be made. Under the Create Tab select



Create Sketch.

When selecting a plane to create the sketch select the outer face of the floor plan as shown in figure 20.



Figure 20: Selecting the Plane for the New Sketch

Once in sketch mode draw a rectangle around the perimeter of the floor plan. To draw a rectangle, go the Create Tab and select Two-Point Rectangle. Draw the rectangle by selecting two points on the floor plan as seen in figure 21.



Figure 21: Drawing a Rectangle Around the Perimeter

Exit sketch mode once the rectangle has been created.

Extruding the Floor

Using the same procedure described earlier extrude the floor by 2.5 mm. When selecting

the profile that needs to be extruded, it may be needed to select multiple profiles.

The finished model should like the one in figure 22.



Figure 22: Finished Model

Exporting as STL File

To export as a STL file, go to the Browser Tab. Expand the bodies section and right click on the body that corresponds to the floor plan. From the menu that appears select Save As STL (shown in figure 23).

In the Save As STL pop-up do not change any of the options just hit ok and save the file on the computer.



Figure 24: Finding the Save As STL Option



Figure 23: The Save as STL Pop-Up