































































































 Attach the cables from the sensors to ports A-D.
Attach the motors cables to ports 1-4.

